

Технические характеристики

По вопросам продаж и поддержки обращайтесь:










Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70












Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47











Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132









Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

IR RECEIVERS - PROXIMITY SENSOR

Part Number	Product Image	Package	Dimensions (mm)	Carrier Frequency (kHz)	Transmission Distance Typ. (m)	Detection Threshold / Sensitivity Typ.	Half Viewing Angle (°)	Supply Current Typ. (mA)	Pinning	Application	Mounting
TSSP4038		Mold	6.0 W x 6.95 H x 5.6 D	38	12	0.4	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP4038SS1XB		Mold	6.0 W x 6.95 H x 5.6 D	38	2.4	7	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP4P38		Mold	6.0 W x 6.95 H x 5.6 D	38	24	0.12	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Proximity sensors	Leaded
TSSP53038		Minimold	6.0 W x 6.95 H x 5.6 D	38	12	0.4	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP53038DF1P		Minimold	6.0 W x 6.95 H x 5.6 D	38	12	0.4	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	SMD
TSSP53038DF1P		Minimold	6.0 W x 6.95 H x 5.6 D	38	12	0.4	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	SMD
TSSP57038		Belobog	3.95 W x 3.95 H x 0.8 D	38	8	0.7	± 75	0.7	1, 4 = GND, 2 = V _S , 3 = OUT	Presence sensors, fast proximity sensors	SMD
TSSP57038H		Belobog shield	3.95 W x 3.95 H x 1.0 D	38	8	0.7	± 75	0.7	1 = OUT, 2, 3, 6, 7, 8 = GND, 4, 5 = V _S	Presence sensors, fast proximity sensors	SMD
TSSP57P38		Belobog	3.95 W x 3.95 H x 0.8 D	38	18	0.2	± 75	0.7	1 = OUT, 2, 3, 6, 7, 8 = GND, 4, 5 = V _S	Proximity sensors	SMD

Part Number	Product Image	Package	Dimensions (mm)	Carrier Frequency (kHz)	Transmission Distance Typ. (m)	Detection Threshold / Sensitivity Typ.	Half Viewing Angle (°)	Supply Current Typ. (mA)	Pinning	Application	Mounting
TSSP58038		Minicast	5.0 W x 6.95 H x 4.8 D	38	8	0.7	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP58P38		Minicast	5.0 W x 6.95 H x 4.8 D	38	18	0.2	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Proximity sensors	Leaded
TSSP6038		Panhead	7.5 W x 5.3 H x 4.0 D	38	8	0.7	± 50	0.7	1 = GND, 2 = N.C., 3 = V _S , 4 = OUT	Presence sensors, fast proximity sensors	SMD
TSSP6P38		Panhead	7.5 W x 5.3 H x 4.0 D	38	18	0.2	± 45	0.7	1 = GND, 2 = N.C., 3 = V _S , 4 = OUT	Proximity sensors	SMD
TSSP77038		Heimdall	6.8 W x 3.0 H x 3.2 D	38	8	0.7	± 50	0.7	1, 4 = GND, 2 = V _S , 3 = OUT	Presence sensors, fast proximity sensors	SMD
TSSP77P38		Heimdall	6.8 W x 3.0 H x 3.2 D	38	18	0.2	± 50	0.7	1, 4 = GND, 2 = V _S , 3 = OUT	Proximity sensors	SMD
TSSP93038		Minimold	5.4 W x 6.35 H x 4.9 D	38	12	0.4	± 45	0.37	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP93038DF1P		Minimold	5.4 W x 6.35 H x 4.9 D	38	12	0.4	± 45	0.37	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	SMD
TSSP94038		Mold	6.0 W x 6.95 H x 5.6 D	38	12	0.1	± 45	0.37	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP95038		Heimdall	6.8 W x 3.0 H x 3.2 D	38	8	0.7	± 50	0.37	1, 4 = GND, 2 = V _S , 3 = OUT	Presence sensors, fast proximity sensors	SMD
TSSP96038		Panhead	7.5 W x 5.3 H x 4.0 D	38	8	0.7	± 50	0.37	1 = GND, 2 = N.C., 3 = V _S , 4 = OUT	Presence sensors, fast proximity sensors	SMD

Part Number	Product Image	Package	Dimensions (mm)	Carrier Frequency (kHz)	Transmission Distance Typ. (m)	Detection Threshold / Sensitivity Typ.	Half Viewing Angle (°)	Supply Current Typ. (mA)	Pinning	Application	Mounting
TSSP98038		Minicast	5.0 W x 6.95 H x 4.8 D	38	8	0.7	± 45	0.37	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP4056		Mold	6.0 W x 6.95 H x 5.6 D	56	12	0.4	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP4056SS1XB		Mold	6.0 W x 6.95 H x 5.6 D	56	2.4	7	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP53056		Minimold	6.0 W x 6.95 H x 5.6 D	56	12	0.4	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP53056DF1P		Minimold	6.0 W x 6.95 H x 5.6 D	56	12	0.4	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	SMD
TSSP53056DF1P		Minimold	6.0 W x 6.95 H x 5.6 D	56	12	0.4	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	SMD
TSSP57056		Belobog	3.95 W x 3.95 H x 0.8 D	56	8	0.7	± 75	0.7	1, 4 = GND, 2 = V _S , 3 = OUT	Presence sensors, fast proximity sensors	SMD
TSSP57056H		Belobog shield	3.95 W x 3.95 H x 1.0 D	56	8	0.7	± 75	0.7	1 = OUT, 2, 3, 6, 7, 8 = GND, 4, 5 = V _S	Presence sensors, fast proximity sensors	SMD
TSSP58056		Minicast	5.0 W x 6.95 H x 4.8 D	56	8	0.7	± 45	0.7	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP6056		Panhead	7.5 W x 5.3 H x 4.0 D	56	8	0.7	± 50	0.7	1 = GND, 2 = N.C., 3 = V _S , 4 = OUT	Presence sensors, fast proximity sensors	SMD

Part Number	Product Image	Package	Dimensions (mm)	Carrier Frequency (kHz)	Transmission Distance Typ. (m)	Detection Threshold / Sensitivity Typ.	Half Viewing Angle (°)	Supply Current Typ. (mA)	Pinning	Application	Mounting
TSSP77056		Heimdall	6.8 W x 3.0 H x 3.2 D	56	8	0.7	± 50	0.7	1, 4 = GND, 2 = V _S , 3 = OUT	Presence sensors, fast proximity sensors	SMD
TSSP93056		Minimold	5.4 W x 6.35 H x 4.9 D	56	12	0.4	± 45	0.37	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP93056DF1P		Minimold	5.4 W x 6.35 H x 4.9 D	56	12	0.4	± 45	0.37	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	SMD
TSSP94056		Mold	6.0 W x 6.95 H x 5.6 D	56	12	0.1	± 45	0.37	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP95056		Heimdall	6.8 W x 3.0 H x 3.2 D	56	8	0.7	± 50	0.37	1, 4 = GND, 2 = V _S , 3 = OUT	Presence sensors, fast proximity sensors	SMD
TSSP96056		Panhead	7.5 W x 5.3 H x 4.0 D	56	8	0.7	± 50	0.37	1 = GND, 2 = N.C., 3 = V _S , 4 = OUT	Presence sensors, fast proximity sensors	SMD
TSSP98056		Minicast	5.0 W x 6.95 H x 4.8 D	56	8	0.7	± 45	0.37	1 = OUT, 2 = GND, 3 = V _S	Presence sensors, fast proximity sensors	Leaded
TSSP-HA		Holder	20.0 W x 13.65 H x 9.0 D	n/a						Presence sensors, proximity sensors	Leaded

По вопросам продаж и поддержки обращайтесь:

Алматы (7273)495-231
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Россия (495)268-04-70

Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Киргизия (996)312-96-26-47

Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Казахстан (7172)727-132

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93